

Alcatel-Lucent Enterprise Network Fleet Supervision


Network inventory & Support visibility made easy
for Customers and Fleet Managers



Free of charge online tool -
Self signup approach



Secure your business with a support
and software compliance tool



Fleet Supervision

Supervise your network device fleet from a single, easy to use platform

- **Take inventory** of all OmniSwitch® and OmniAccess Stellar® devices for asset management purpose and confirm **proper support entitlement status**
- Visualize key information related to a set of devices for a **proactive service and support management**
- Track **hardware lifecycle** and plan budget for replacement (end of sales, end of life)
- Check current software version and **plan proactive updates**



Cut operational costs
and streamline support
services through real-time
device visibility




Take control of your network
from a single dashboard —
stay ahead with smart
updates and timely hardware
refreshes


ALE Fleet Supervision

Empowering end customers with Support Entitlement visibility and software compliance

- **Automatic asset inventory** - Display devices managed by several OmniVista management systems
- Manual option to **import serial numbers** for unmanaged devices or assets behind firewall
- **Inventory management** with drill down and sorting flexibility
- **Key info** - Summary and detailed view of OmniSwitch chassis, power supplies, transceivers and OmniAccess Stellar access points
- **Service/support status**, device lifecycle warranty, software version



- Instant visibility on **software running version**
- **Assess and control your compliance** (e.g. NIS2)
- **Service & support entitlement ratio**
- **Device lifecycle & warranty ratio**
- All **software versions** displayed at a glance
- Easy **report** exports



All of your network assets at your fingertips

Your service and maintenance status at-a-glance

Software updates made easy, simplifying software versioning